

FOR HPT770 PLOTTER AND T3500 CATEGORY USAGE

- 1. Menu**
- 2. Internal Prints**
- 3. User Information Prints**
- 4. Print Usage Report**

FOR T730/T830 PLOTTER

- 1. Swipe down on User Panel**
- 2. Touch gear icon**
- 3. Scroll down to Reports**
- 4. Select Printer Status Report**

FOR T795, T1300 & T2300 PLOTTER

- 1. Touch (i) for information**
- 2. Go to wrench**
- 3. Scroll down to Internal Prints**
- 4. Touch User Info Prints**
- 5. Print Usage Report**

FOR T2500 PLOTTER

- 1. Press double gear icon**
- 2. Press single gear icon**
- 3. Press Internal prints**

4. Press User information prints

5. Press Print usage report

FOR T3500 PLOTTER

1. At Main Screen, swipe to left

2. Meter will display on Screen

3. Send Area/ Square Foot Reading and ink usage

**Please send usage report to Cathy Ledford @ 704-333-3849 or email
to cathy.ledford@duncan-parnell.com**